




User's Manual for Key Safe

Read all instructions before using this safe.

WARNING

- For security purposes, change the factory default code as soon as possible. Factory default code is 159 and 011223.
- Test registered pin code a few times before closing the safe door.
- Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the safe, gaining full access to the safe and its contents.
- Store emergency keys in a secure place; NOT inside of the safe.
- To maximize security and performance of the safe, test pin code every 6 months.
- Test and make sure the safe works properly before mounting. Once tested, mount the safe before use.

PARTS OF THE SAFE



- A. Handle
- B. Key Access
- C. Key Pad
- D. Indicator Lights
- E. Key Drop Slot
- Located on the side of the safe

GETTING STARTED

Remove emergency keys and other included accessories from packaging.

KEY ACCESS

1. Remove grey key cover located on the safe to expose key hole.
2. Use emergency key and insert into key hole, turn key counter clockwise and turn handle clockwise.

BATTERY

Battery compartment is located on the inside of the door safe.

1. Remove battery compartment cover.
2. Insert four AA alkaline batteries into the battery compartment and restore battery compartment cover.

Note: Do not mix new and old batteries

PIN CODE REGISTRATION

1st Safe Default Pin Code : 159
 2nd Safe Default Pin Code : 011223

1. Press "** **", then yellow indicator light next to warning will light up.
2. Input current user code that you want to change, and press "#".
3. Input your new pin code you want to change it to and press "#".
4. Input your new pin code one more time to confirm registration and press "#." Yellow light will turn off, meaning code has been registered.

Repeat steps above to change second pin code


TESTING REGISTERED PIN CODE

With safe door open turn handle counter clockwise to extend the bolts. Enter registered pin code and press "#" safe should unlock. Turn handle clockwise and bolts shall retract; if safe unlocked then registration is complete.

Note: If safe does not unlock then pin code registration was unsuccessful. Please start over with Pin Code Registration.

DELETING PIN CODES / RESETTING SAFE TO FACTORY DEFAULT MODE

Please only reset the safe if Pin Codes are lost or forgotten.



1. Open safe and remove screws securing the back cover to the safe.
2. You will see a small button located on the circuit board.
3. Press and hold small button until you see all the lights flash and 2 quick beeps will be heard.
4. All pin codes have been reset to factory Default Pin Codes.

Note: 1st Safe Default Pin Code : 159
 2nd Safe Default Pin Code : 011223

LOW BATTERY WARNING

The Red Light comes with Green Light while entering pin code.

LOCK OUT MODE

If the wrong codes are entered 3 times consecutively, the keypad will not accept any code, the beep sound will last for 20 seconds.

If the wrong codes are entered 6 times consecutively, the keypad will not accept any code for 5 minutes and the beep sound lasting. You can remove all batteries to terminate the lockout.

MOUNTING INSTRUCTIONS

The safe may be mounted to a wall. Be aware of the load bearing. Failure to do so can result in personal injury and/or damage to property. Use appropriate tools when performing work and always use eye protection.

- Do not mount the safe without anchoring to the wall.
- Find the studs in the wall, at your desired location. Most studs are 16 inches or 24 inches apart.
- Check the wall for concealed wires or pipes.
- Measure the location of the pre-set drill holes; mark their exact position onto the wall ensuring that the studs or anything else behind will not interfere.
- Drill the appropriate size holes for the anchors you are using.
- Carefully press the anchor into the holes at this time.
- Mount the safe by running screws from inside of the safe and securing to anchors; ensure the safe is mounted securely.

CARE AND MAINTENANCE

- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock.
- Secure safe in a proper area to prevent from falling and causing damage or injury.
- DO NOT disassemble the product. For all repairs, contact BARSKA Customer Service.
- DO NOT use chemicals or cleaning agents to clean the safe.

Note: All information, feature, and specification displayed herein are based on the data available at the time of publishing, thus they are subject to change without notice. All product pictures displayed herein are for illustration purposes only. The actual product may vary due to different circumstances



1 YEAR LIMITED WARRANTY

SAFE/LOCK BOX

BARSKA warrants this new safe/lock box to be free of defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is purchased. This limited warranty is delimited to repair or replacement only. This warranty does not cover damage caused by improper installation or maintenance. BARSKA disclaims all liability for incidental or consequential damages resulting from misuse, abuse, accident (such as dropping), fire, flood, service or repairs other than those performed by BARSKA, acts of nature, or arising out of any breach of this warranty. Altering the product under any circumstances will automatically void the warranty.

For service under this limited warranty, please have available the proof of purchase and the purchase date and location as well as a detailed description of the problem. This warranty is not transferable and only applies to the original purchaser with a proof of purchase from BARSKA or from an authorized dealer. This warranty applies only to products purchased within the United States, excluding Alaska, the Hawaiian Islands and all U.S. territories in the Caribbean and the Pacific.

BARSKA will examine and go through troubleshooting procedures, product repair or replacement of defective part(s) or units with new part(s) or provide a new unit, if necessary, during the warranty period. Reasonable shipping/handling charges may apply and are based on Barska sole discretion. Purchaser shall be required to prepay Shipping/handling charges with a check or money order to BARSKA at time product is returned. The Return Merchandise Authorization Number (RMA#) and shipping/handling charge MUST be obtained from BARSKA in advance of return. BARSKA shall not be liable for damages or loss occurring during shipping. Please visit via www.barska.com or call 909.445.8168 to obtain the RMA#, Shipping/handling amount, and for more information.

BARSKA reserves the right to modify or discontinue, without prior notice to the purchaser, any model or style of the product. BARSKA will determine, at its sole discretion, whether a product will be repaired or replaced. BARSKA reserves the right to discontinue or change any feature of its products at any time. If an exact replacement or product is not available, BARSKA reserves the right to provide a part or product that matches as closely as possible.

LIMITATION OF REMEDIES

BARSKA disclaims any warranties, express or implied, whether of merchantability or fitness for a particular use, except as expressly set forth herein. The sole obligation of BARSKA under this limited warranty shall be to repair or replace the covered product, in accordance with the terms set forth herein. BARSKA expressly disclaims any lost profits, general, special, indirect or consequential damages which may result from breach of any warranty, or arising out of the use or inability to use any BARSKA product. Any warranties which are implied and which cannot be disclaimed shall be limited in duration to a term of one year from the date of original retail purchase.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

BARSKA
855 Towne Center Drive, Pomona, CA 91767