


Key Cabinet with Combination Lock

Please keep your keys in safe place, not inside the key cabinet. The keys can be used to open the key cabinet.

Parts Of The Combination Lock

- A. Knob
- B. Number Dial
- C. Alignment Line
- D. Aftercoder
- E. Reset Button



Setting Personal Combination Code

- Turn the number dials to the preset combination code 0-0-0-0, and turn the knob to open the Lock.
- When knob is at the open position, switch the Reset button to "B" position. Figure 1
- Turn the number dials to set the new Personal combination code. Note the code needs to be align to the alignment line.
- Switch the Reset button to "A" position, and test the new Personal combination code before you close the door. See figure 2




Figure 1




Figure 2

Unlock And Lock The Cabinet Using Combination Code

- Turn the number dials to personal combination.
- Turn the knob to open the cabinet.
- Close and turn the number dials to random numbers to lock the cabinet.

Unlock And Lock The Cabinet Using Key

- Insert the Key and turn the knob to open the cabinet.
- Turn the key to the close position to lock the cabinet.

How To Find The Combination Code

If you forget your combination code, follow below procedure to find the Combination Code.

- Use the key to open the door, while the door is open, turn the knob back to close position and withdraw the key.
- Press and hold each Aftercoder, and slide the number dials one by one till the dial can't move to get the forgotten combination code. Repeat this number on all 4 dials. After find the number, test the combination code before you close the door.




Figure 3

1 YEAR LIMITED WARRANTY

SAFE/LOCK BOX

BARSKA warrants this new safe/lock box to be free of defects in material and/ or workmanship under normal use for a period of twelve (12) months from the date product is purchased. This limited warranty is delimited to repair or replacement only. This warranty does not cover damage caused by improper installation or maintenance. BARSKA disclaims all liability for incidental or consequential damages resulting from misuse, abuse, accident (such as dropping), fire, flood, service or repairs other than those performed by BARSKA, acts of nature, or arising out of any breach of this warranty. Altering the product under any circumstances will automatically void the warranty.

For service under this limited warranty, please have available the proof of purchase and the purchase date and location as well as a detailed description of the problem. This warranty is not transferable and only applies to the original purchaser with a proof of purchase from BARSKA or from an authorized dealer. This warranty applies only to products purchased within the United States, excluding Alaska, the Hawaiian Islands and all U.S. territories in the Caribbean and the Pacific.

BARSKA will examine and go through troubleshooting procedures, product repair or replacement of defective part(s) or units with new part(s) or provide a new unit, if necessary, during the warranty period. Reasonable shipping/handling charges may apply and are based on Barska sole discretion. Purchaser shall be required to prepay Shipping/handling charges with a check or money order to BARSKA at time product is returned. The Return Merchandise Authorization Number (RMA#) and shipping/handling charge MUST be obtained from BARSKA in advance of return. BARSKA shall not be liable for damages or loss occurring during shipping. Please visit via www.barska.com or call 909.445.8168 to obtain the RMA#, Shipping/handling amount, and for more information.

BARSKA reserves the right to modify or discontinue, without prior notice to the purchaser, any model or style of the product. BARSKA will determine, at its sole discretion, whether a product will be repaired or replaced. BARSKA reserves the right to discontinue or change any feature of its products at any time. If an exact replacement or product is not available, BARSKA reserves the right to provide a part or product that matches as closely as possible.

LIMITATION OF REMEDIES

BARSKA disclaims any warranties, express or implied, whether of merchantability or fitness for a particular use, except as expressly set forth herein. The sole obligation of BARSKA under this limited warranty shall be to repair or replace the covered product, in accordance with the terms set forth herein. BARSKA expressly disclaims any lost profits, general, special, indirect or consequential damages which may result from breach of any warranty, or arising out of the use or inability to use any BARSKA product. Any warranties which are implied and which cannot be disclaimed shall be limited in duration to a term of one year from the date of original retail purchase.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

BARSKA
855 Towne Center Drive, Pomona, CA 91767

BC767