


User Manual for iBOX® Dual Biometric Secure Storage Device

Read all instructions before using this storage device

WARNING

- New storage device is in factory default mode, ANY fingerprint can open the storage device. Only successful registration of fingerprint can terminate Factory Default Mode.
- Default mode will allow any finger to access the storage device but when accessing the storage device the red indicator light will flash and several beeps will be heard. If this happens storage device is still in factory default mode; please register a fingerprint.
- Register at least two different fingerprints and test a few times before closing the storage device.
- Storage Device must remain upright when operating. Failure to do so might cause bolts to get stuck even with accepted fingerprint.
- Avoid leaving storage device door open and unattended it will allow unauthorized individuals to add their fingerprints and/or reprogram the storage device, gaining full access to the storage device and the contents.
- Test the security and performance of the storage device every 6 months.
- Operation Temperature: 32°F – 113°F (0°C – 45°C)
Operation Humidity: 45% – 85% RH
- Only use Alkaline batteries. Do not mix old and new batteries.

PARTS OF THE STORAGE DEVICE



- A. Battery Compartment (Underneath)
B. Indicator Light
C. Fingerprint Scanners
D. Initialization Button (Inside)

INSTALL BATTERIES

The Battery Compartment is located underneath the storage device.

1. Remove Battery Compartment Cover by loosening the two screws that are securing it.
2. Insert 4 AA Alkaline batteries and restore battery cover and screws.

NOTE: Do not mix old and new batteries.

OPERATIONAL INFORMATION

- Initialization Button is located on the inside of the storage device.
- Storage device retains 2 master fingerprints and 118 user fingerprints.
- Master fingerprint is required to register additional user fingerprints.
- Successful Registration: 2 beeps will be heard and green indicator light flashes.
- Unsuccessful Registration: 2 quick beeps are heard and red indicator light flashes then registration has failed; please repeat registration process.

MASTER FINGERPRINT REGISTRATION

There are 2 methods to register Master Fingerprints.

Method 1

Place both desired master fingers on the Fingerprint Scanners simultaneously and hold until 2 beeps are heard and green Indicator Light flashes.

Method 2

1. Register 1st master fingerprint:
With a small pin like tool press Initialization Button, place desired master finger on Fingerprint Scanner that lights up and hold until 2 beeps are heard and green Indicator Light flashes.
2. Register 2nd master fingerprint:
With a small pin like tool press Initialization Button, place 1st master finger on the Fingerprint Scanner that lights up, 1 beep will be heard, then place desired 2nd master finger on Fingerprint Scanner and hold until 2 beeps are heard and green Indicator Light flashes.

TEST MASTER FINGERPRINTS

With the storage device closed, place a registered master finger on Fingerprint Scanner. Storage device should open and green Indicator Light will flash. Test both master fingerprints. If storage device opens and red Indicator Light is seen then storage device is still in factory default mode. Please follow steps under MASTER FINGERPRINT REGISTRATION again.

USER FINGERPRINT REGISTRATION

With a small pin like tool press Initialization Button and place a master finger on the Fingerprint Scanner that lights up, 1 beep will be heard, then place desired user finger on Fingerprint Scanner and hold until 2 beeps are heard and green Indicator Light flashes.

TEST REGISTERED USER FINGERPRINT

With the storage device closed, place a registered finger on Fingerprint Scanner. Storage device should open and green Indicator Light will flash. If storage device does not open registration failed, please follow steps under USER FINGERPRINT REGISTRATION again.

OPEN/CLOSE DOOR

Open: Place registered fingerprint on Fingerprint Scanner and hold until door opens.

Close: Close lid of the storage device.

SOUND OPTION

To turn the sound on/off, with a small pin like tool press and hold the Initialization Button for about 10 seconds until a beep is heard and green Indicator Light flashes.

DOOR OPEN ALARM

If sound is on, alarm will activate after storage device door is open for 1 minute.

If sound is off, alarm will not activate.

DELETE ALL STORED FINGERPRINTS RESET TO FACTORY DEFAULT MODE

1. With storage device door opened, remove Battery Compartment Cover by loosening the two screws that are securing it.
2. With a small pin like tool press and hold the initialization Button while you hold the Battery Compartment in place until 2 beeps are heard and green light flashes.
3. All fingerprints are now reset and storage device is in factory default mode. Replace two screws securing the Battery Compartment Cover.

NOTE: Any fingerprint can open the storage device. Red Indicator Light will be seen when accessing the storage device.

LOW BATTERY WARNING

When accessing the storage device, an alarm sound goes off but access is granted. This means batteries are low and should be replaced immediately.

Note: If batteries are too low storage device will not work properly. Please test storage device every 6 months to ensure product is working properly.

NOTE: Do not mix old and new batteries.

CARE AND MAINTENANCE

- To maximize the security and performance of the storage device, keep Fingerprint Scanner clean; use a dry cloth to remove any smudges or prints off the Fingerprint Scanner after each use.
- Test registered fingerprints every 6 months.
- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock.
- Secure storage device in a proper area to prevent from falling and causing damage or injury.
- DO NOT disassemble the product. For all repairs, contact BARSKA Customer Service.
- DO NOT use chemicals or cleaning agents to clean the storage device.

COMMON ISSUES

Issue	Solution
Storage device lets me in but I see red indicator light.	Storage device is in factory default mode register master fingerprint.
Storage device makes an alarm when accepting fingerprint.	Storage device is low on battery, change the batteries.
Storage device does not work, or open.	
Storage device door cannot close.	Bolt is currently locked, place finger on fingerprint scanner to unlock storage device.
Storage device has no sound.	Sound is off, with a tool press and hold the initialization button.



1 YEAR LIMITED WARRANTY

Storage Device

BARSKA warrants this new device to be free of original defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is received by purchaser. This warranty does not include damage caused by improper installation or maintenance. Damage from misuse, abuse, accident (such as dropping), normal wear and tear, fire, flood, or acts of nature. Damage from service or repairs other than those performed by BARSKA. Labor, cost and shipping charges for the removal and replacement of defective parts beyond the initial twelve-month warranty period. All transportation and shipping charges. Removing or altering the seal under any circumstances will automatically void the warranty.

This warranty is limited to original purchaser and is not transferable. This warranty applies only to products purchased in the United States.

Please email info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. The RMA number must appear on the outside of the shipping package. Product must be packed carefully and sturdily in its original packaging to prevent damage in transit and returned freight pre-paid to:

BARSKA OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
 2. Purchase receipt or Proof of Purchase. (Original/Copy)
 3. A brief explanation of the defect.
 4. A Check/Money Order of \$30.00 to cover inspection, shipping and handling.
- *Please allow 6-8 weeks for delivery.

BARSKA will examine and test returned product and repair or replace defective part(s) or units with new part(s) or a new unit if necessary within the warranty period. Purchaser is required to remit \$30.00 to BARSKA for return shipping and handling at time product is returned. If repair is required after warranty period expiration, purchaser will be charged for replacement parts and return shipping.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.